

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

JUL 24

5a. Indicate Type of Lease	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	OG-5121

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	None
3. Address of Operator	8. Farm or Lease Name
P. O. Box 728, Hobbs, New Mexico 88240	New Mexico "DG" State
4. Location of Well	9. Well No.
UNIT LETTER J 2310 FEET FROM THE South LINE AND 1980 FEET FROM	1
THE East LINE, SECTION 18 TOWNSHIP 17-S RANGE 37-E NNPM.	10. Field and Pool, or Wildcat
	Undesignated San Andres
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3804' (D. F.)	Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The following work has been completed on subject well:

1. Pull rods, pump, and tubing.
2. Run GN - Sonic log from 4500' - 5500'.
3. Set Bridge plug in 4 1/2" od casing at 5400'.
4. Perforate 4 1/2" od casing w/1 JSPF 5053' - 5070'.
5. Acidize perforations perforations w/ 500 gals. 15% NE acid
6. Perforate 4 1/2" od casing w/1 JSPF 5134' - 5140', 5240' - 5250', & 5253' - 5270'.
7. Acidize perforations 5134' - 5270' w/1000 gals 15% NE acid.
8. Acidize perforations 5053' - 5270' w/ 2500 gals 28% NE acid in 4 stages using 300% salt between stages. Overflushed casing w/ 18 bbls. 3% acid.
9. Pull Packer, swab, test, return to production.

NOTE: Well is now producing from the San Andres.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Assistant District
Superintendent

SIGNED

TITLE

DATE

July 24, 1968

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: