

DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-102
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> T.A. GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company		8. Farm or Lease Name C. M. Selby
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201		9. Well No. 2
4. Location of Well UNIT LETTER <u>A</u> <u>990</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>18</u> TOWNSHIP <u>17-S</u> RANGE <u>37-E</u> NMPM.		10. Field and Pool, or Wildcat Midway-Abo
15. Elevation (Show whether DF, RT, GR, etc.) 3790' GR		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has been shut in since 1968 and is not a commercial producer.
We propose to P & A as follows:

1. Set CIBP in 4½" casing @ 8800' and cap w/20 sx of cement.
2. Cut off and recover 4½" csg from free point (top of cement @ 7000').
3. Set these cement plugs: 30 sx in & out of 4½" stub, 30 sx across Glorieta (Top at 6568') and 30 sx across 8-5/8" shoe @ 4791'.
4. Cut off and recover 8-5/8" csg from free point (Top of cement @ 2210').
5. Set these cement plugs: 30 sx in & out of 8-5/8" stub, 30 sx across 13-3/8" shoe @ 350' and 10 sx in top of well.
6. Will use 9#/gal salt gel mud to spot all plugs; erect dry hole marker and clear and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>D.D. Sutchus</u>	TITLE <u>Dist. Drlg. Supervisor</u>	DATE <u>8-13-70</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT</u>	DATE <u>AUG 12 1970</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

AUG 17 1970

OIL CONSERVATION COMM.
HOUSTON, TEXAS