

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-24026
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS. (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Lease Name or Unit Agreement Name Ritts State Co
2. Name of Operator Chevron U.S.A. Inc.	8. Well No. 2
3. Address of Operator P.O. Box 670, Hobbs, NM 88240	9. Pool name or Wildcat Vacuum Grayburg/San Andres
4. Well Location Unit Letter <u>H</u> : <u>2080</u> Feet From The <u>North</u> Line and <u>560</u> Feet From The <u>East</u> Line Section <u>21</u> Township <u>17S</u> Range <u>34E</u> NMPM Lea County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) <u>4058'</u>	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <u>Abandon DB/SA</u> <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to abandon the Grayburg-San Andres zone and turn wellbore over to N. Vacuum Abo West Unit (Texaco Op), as follows:

POH w/PE. Engage RBP @ 4785'. Unset, move and reset to ensure RBP is functioning. Reset at $\pm 4800'$ & test to 500psi, Spot sand on RBP, Set pkr at $\pm 4450'$. Load BS and test to 500psi, Establish inj rate and press into G/SA perms at 4532-4724. POH w/pkr. Set CICR at $\pm 4450'$. Sqz Grayburg/SA perms. Drill out and test sqz'd perms to 500psi, check for FE. Circ. hole clean. POH w/ RBP, Install WH, RDMOPU. Turn over to Texaco.

Work is to be performed as an operating necessity.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE LK Elmer TITLE Technical Asst. DATE 4-21-89

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE APR 25 1989

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

U.S. DEPARTMENT OF JUSTICE

APR 24 1989

CCD

HOOD 02203