

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-3196

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Southland Royalty Company	8. Farm or Lease Name Conoco AZ State Comm.
3. Address of Operator 1100 Wall Towers West, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER <u>L</u> , <u>1874</u> FEET FROM THE <u>South</u> LINE AND <u>766</u> FEET FROM THE <u>West</u> LINE, SECTION <u>22</u> TOWNSHIP <u>17-S</u> RANGE <u>34-E</u> NMPM.	10. Field and Pool, or Wildcat Vacuum ABO North
15. Elevation (Show whether DF, RT, GR, etc.) 4057' Gr	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Pull rods & tubing. Ran csg spear inside 4½" csg. Pull up slips & released tension on csg. Make up torque in 4½" csg, 1 full round. Ran pkr & found sli bleed off in press. inside csg at 110'. P.O.H. w/pkr. Reinstall slips & pack off. Reinstall spool & BOP. Wellex dump 1 sx sd on RBP @ 5000'. Perf @ 3550' w/4 JSPF. Ran pkr to 180'. Set pkr & established circ behind csg. Pull pkr & ran cmt retainer to 3500'. Cmt w/500 sxs HLW + 200 sxs C1 C w/2% C.C. Cmt circ. Drl out retainer. Circ sand off RBP. Pull RBP. Ran pump & rods. Resume production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

By <u>Donald R Craig</u>	TITLE <u>District Production Engineer</u>	DATE <u>4/16/80</u>
APPROVED BY <u>Lerry Sermon</u>	TITLE <u>District Engineer</u>	DATE <u>MAY 19 1980</u>
CONDITIONS OF APPROVAL, IF ANY:		