

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.C.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Texas International Petroleum Corp.	8. Farm or Lease Name Byers
3. Address of Operator P. O. Box 4520, Shreveport, La. 71104	9. Well No. 1
4. Location of Well UNIT LETTER M 660 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 12 TOWNSHIP 17S RANGE 37E NMPM.	10. Field and Pool, or Wildcat Humble City (Atoka)
15. Elevation (Show whether DF, RT, GR, etc.) 3228.6 G.R.	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- (1) Set 100' cement plug (12 sxs.), across perf. 11659' to 11692', from 11,600' to 11,700'.
- (2) Load hole with 9.5 p.p.g. salt brine mud. P.O.O.H. with tubing
- (3) Shot 5-1/2" 17.00# Csg. off @ free point and pull out of hole.
- (4) G.I.H. with tubing and spot 100' cement plug (22 sxs.) In and out of 5-1/2" Csg. stub
- (5) Spot a 100' cement plug (30 sxs.) @ top of Abo (8918') and Glorieta (6834') if not behind pipe.
- (6) Spot a 100' cement plug (30 sxs.) @ 8-5/8" shoe from 4750' to 4850'.
- (7) Shot 8-5/8" Csg. off @ free point. Lay same down. Place a 100' cement plug (43 sxs) in and out of 8-5/8" Csg. stub.
- (8) Spot a 100' cement plug (56 sxs) at top (2261') and at base (3254') of salt section if not behind pipe.
- (9) Spot a 100' cement plug (64 sxs) at 12-3/4" show from 372' to 472'.
- (10) Place a 10 sack cement plug at surface with marker

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Vice President - Operations DATE Sept. 29, 1975

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: