

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5c. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-5303
7. Unit Agreement Name
8. Farm or Lease Name Quail State
9. Well No. 1
10. Field and Pool, or Wildcat Scharb Bone Spring Ext.
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER Dry hole
2. Name of Operator Union Oil Company of California
3. Address of Operator P.O. Box 671 - Midland, Texas 79701
4. Location of Well UNIT LETTER I , 1839 FEET FROM THE south LINE AND 519 FEET FROM THE east LINE, SECTION 3 TOWNSHIP 19-S RANGE 34-E N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) 3989' GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

5-3-74 to 5-20-74: Drilled 7-7/8" hole to 10600' T.D.

Proposed plugging procedure:

Set 50 sx plug @ 10246'
" " " " " 6084'
" " " " " 5333'
" 75 " " across 8-5/8" casing shoe @ 3990'
Cut & pull 8-5/8" casing from free point
Set 100 sx plug @ 806'
" " " " across 11-3/4" casing shoe @ 400'
" 10 " " 20' to surface
Weld on steel plate & install abandonment marker

100' Plug at top of Bone Springs @ 8037

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>L. L. White</i>	TITLE Actg. Dist. Dirg. Supt.	DATE July 26, 1974
APPROVED BY <i>John W. Remyan</i>	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		