

Submit 3 Copies  
to Appropriate  
District Office.

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.

50-025-26723

5. Indicate Type of Lease

STATE ☐

FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name

Warren

8. Well No.

1

9. Pool name or Wildcat

Wildcat (Wolfcamp)

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL

WELL ☒

GAS

WELL ☐

OTHER

2. Name of Operator

Barbara Fasken

3. Address of Operator

303 W. Wall, Suite 1900, Midland, Texas 79701

4. Well Location

Unit Letter G : 2080 Feet From The North Line and 1980 Feet From The East Line

Section

8

Township

17-S

Range

37-E

NMPM

Lea

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3784.1' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well should attempt to recomplete in wolfcamp be unsuccessful.

1. Displace well with 9.5#/gal. salt mud.

2. Spot 25 sx Class "H" cement at 9600'. (Wolfcamp perms 9652'-9664' below plug).

3. Spot 25 sx Class "C" cement at 8300'. (Abo below plug).

4. Spot 25 sx Class "C" cement at 6300'. (Glorietta below plug).

5. Spot 60 sx Class "C" cement at 4900'. (San Andres below plug, 8-5/8" casing shoe at 4396'). Tag this plug.

6. Cut off 5-1/2" casing at 4300'. Pull and recover casing.

7. Spot 30 sx Class "C" cement at 2100' (Salt section below plug)

8. Spot 30 sx Class "C" cement at 450'. (13-3/8" shoe at 400').

9. Spot 10 sx Class "C" surface plug.

10. Cut off wellhead 3' below ground level.

11. Install 4" x 7' dry hole marker.

12. Rig down plugging equipment and level location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Jimmy Davis Jr*

TITLE Drilling & Operations Supt. DATE 11-27-89

TYPE OR PRINT NAME

Jimmy Davis, Jr.

TELEPHONE NO. 915-687-1777

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

DEC 01 1989