

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-27235
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-1113-1
7. Lease Name or Unit Agreement Name Central Vacuum Unit
8. Well No. 154
9. Pool name or Wildcat Vacuum Grayburg San Andres
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3987 GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☐ GAS WELL ☐ ~~OTHER~~ Water Injection Well

2. Name of Operator *Texaco*
Texas Exploration & Production, Inc.

3. Address of Operator
P.O. BOX 3109 Midland, TX. 79701

4. Well Location
Unit Letter *D* : 45 Feet From The North Line and 1185 Feet From The West Line
Section 30 Township 17 S Range 35 E NMPM Lea County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data.	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1.) Notify N.M.O.C.D. of intent to Plug & Abandon well.
- 2.) Set CICR at 4500' & sqz .65 sxs. class c cement below retainer into perf. at 4549-4622'. Unsting from retainer & cap w/35' of cement.
- 3.) Circulate well bore w/9.5# mud.
- 4.) Spot 25 sxs cement plug from 2939' - 2839' (T. Yates @ 2889)
- 5.) Spot 25 sxs cement plug from 2790' - 2690' (B-Salt)
- 6.) Spot 35 sxs cement plug from 1782' - 1643' (T-Salt 1732')
- 7.) Spot 40 sxs cement plug from 400' - surface.
- 8.) Cut off wellhead; cap well; install dry hole marker; clean off location. Rig down.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *R.J. Harding* TITLE Operations Engineer DATE 3/2/96

TYPE OR PRINT NAME R.J. Harding III TELEPHONE NO. 915-688-4816

(This space for State Use)

Original filed at

MAR 21 1996

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: