

Submit 3 Copies
to Appropriate
District Office.

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-27274
5. Indicate Type of Lease	STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.	17476
7. Lease Name or Unit Agreement Name	Warren
8. Well No.	3
9. Pool name or Wildcat	Midway Devonian
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	3786.1' GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	2. Name of Operator Barbara Fasken
3. Address of Operator 303 W. Wall, Suite 1900, Midland, Texas 79701-5116	4. Well Location Unit Letter F : 2310 Feet From The North Line and 2310 Feet From The West Line Section 8 Township 17-S Range 37-E NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3786.1' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set C.I.B.P. at 11,750' on wireline.
2. Displace well with 9.5 ppg salt mud.
3. Spot 15 sx Class "H" cement on top of C.I.B.P. (Devonian below plug).
4. Spot 25 sx Class "H" cement at 8300'. (Abo below plug).
5. Spot 25 sx Class "C" cement at 6300'. (Glorietta below plug).
6. Spot 60 sx Class "C" cement at 4800'. (San Andres below plug, 8-5/8" shoe plug).
7. Cut 5-1/2" casing at +3850' and P.O.W.
8. Spot 45 sx Class "C" cement 50' into casing stub. Tag this plug.
9. Spot 30 sx Class "C" cement at 2000'. (Salt section below plug).
10. Spot 30 sx Class "C" cement at 439'. (13-3/8" surface shoe at 389').
11. Spot 10 sx Class "C" cement at surface.
12. Cut off 13-3/8" and 8-5/8" casing 4 feet below ground level. Weld on cap and 4" x 8' dry hole marker.
13. Remove mast anchor & level (lower)

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jimmy Davis Jr. TITLE Dir. & Operations Supt. DATE 9-26-91
TYPE OR PRINT NAME Jimmy Davis, Jr. TELEPHONE NO. 915-687-1777

(This space for State Use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

THE COMMISSIONER MUST BE NOTIFIED 24
HOURS BEFORE THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-101

13. ~~Remove mast anchors and level location.~~

170.49

SEP 11 1991

1000 1000