

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

APR 12 1994

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.

30 025 27394

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

18615

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL  
WELL ☒

GAS  
WELL ☐

OTHER

7. Lease Name or Unit Agreement Name

Consolidated State

2. Name of Operator

Barbara Fasken

8. Well No.

2

3. Address of Operator

303 W. Wall, Suite 1900, Midland, TX 79701

9. Pool name or Wildcat

Midway (Strawn)

4. Well Location

Unit Letter A : 990 Feet From The East Line and 990 Feet From The North Line

Section 8 Township 17 Range 37 NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3779'

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

REMEDIAL WORK ☐

ALTERING CASING ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

PULL OR ALTER CASING ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 10,650' w/35 feet cmt. on top using wireline dump bailer.
2. Displace well with 9.5 ppg salt mud.
3. Spot 25 sx Class "H" cement @ 8800' (Abo plug).
4. Spot 25 sx Class "C" cement @ 6300' (Glorietta plug).
5. Spot 25 sx Class "C" cement @ 4500' (8-5/8" shoe plug).
6. Cut 5-1/2" casing @ ±4000' and POW.
7. Spot 25 sx Class "C" cement 50' into casing sub. Tag this plug.
8. Spot 40 sx Class "C" cement @ 2000' (salt plug).
9. Spot 10 sx Class "C" cement @ surface.
10. Cut off 13-3/8" and 8-5/8" casing 3 feet below ground level. Weld on cap and 4" x 8' dry hole marker.
11. Remove mast anchors and level location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Carl W. Brown

TITLE

Petroleum Engineer

DATE

4-6-94

TYPE OR PRINT NAME

Carl W. Brown

TELEPHONE NO. 915-687-17

(This space for State Use)

APPROVED BY

TITLE

DATE

JAN 17 1995

CONDITIONS OF APPROVAL, IF ANY: