

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
ENR Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30 025 27394
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 18615
7. Lease Name or Unit Agreement Name Consolidated State
8. Well No. 2
9. Pool name or Wildcat Midway (Strawn)
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3779'

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Barbara Fasken
3. Address of Operator 303 W. Wall, Suite 1900, Midland, TX 79701

4. Well Location Unit Letter <u>A</u> : <u>990</u> Feet From The <u>East</u> Line and <u>990</u> Feet From The <u>North</u> Line Section <u>8</u> Township <u>17</u> Range <u>37</u> NMPM Lea County
--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER: <input type="checkbox"/>	SUBSEQUENT REPORT OF: REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 10,650' w/35 feet cmt. on top using wireline dump bailer.
2. Displace well with 9.5 ppg salt mud.
3. Spot 25 sx Class "H" cement @ 8800' (Abo plug).
4. Spot 25 sx Class "C" cement @ 6300' (Glorietta plug).
5. Spot 25 sx Class "C" cement @ 4500' (8-5/8" shoe plug).
6. Cut 5-1/2" casing @ ±4000' and POW.
7. Spot 25 sx Class "C" cement 50' into casing sub. Tag this plug.
8. Spot 40 sx Class "C" cement @ 2000' (salt plug).
9. Spot 10 sx Class "C" cement @ surface.
10. Cut off 13-3/8" and 8-5/8" casing 3 feet below ground level. Weld on cap and 4" x 8' dry hole marker.
11. Remove mast anchors and level location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Carl W. Brown TITLE Petroleum Engineer DATE 4-6-94  
TYPE OR PRINT NAME Carl W. Brown TELEPHONE NO. 915-687-1777

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

APR 11 1994

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: