

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State Federal

5. State Oil & Gas Lease No.  
NM 40450

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> GAS <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <u>Amoco Production Company</u>	8. Farm or Lease Name <u>Federal CS Com</u>
3. Address of Operator <u>P. O. Box 68, Hobbs, New Mexico 88240</u>	9. Well No. <u>1</u>
4. Location of Well UNIT LETTER <u>F</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>7</u> TOWNSHIP <u>18</u> RANGE <u>32</u> N.M.P.M.	10. Field and Pool, or Wildcat <u>Wildcat Bone Spring</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>3786.3</u>	12. County <u>Lea</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to directional drill to sidetrack-collapsed casing per the following:  
Run cement retainer set at 1800'. Establish injection rate. Sting into cement retainer and squeeze with 500 sacks class H cement with 3% CaCl. If during cementing there is circulation out bradenhead shut off cement after a minimum of 100 sacks. WOC 12 hours. Washover 8-5/8" casing from surface to 1000'. Recover 8-5/8" casing to 1000'. Spot cement plug 50' in and 50' out of 8-5/8" casing stub. Kick off at 1000' and directionally drill to 2600' with a 12-1/2" bit. Run 8-5/8" 32# casing set at 2600'. Circulate cement to surface. Drill out and attempt to re-enter old hole below 2600'. Verbal approval Cox-Stewart, USGS and Cox Clements, NMOCDD 2-18-82.

0+6-USGS, R 1-Hou 1-W. Stafford, Hou 1- DMF 1-Susp

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mark Freeman TITLE Assist. Admin. Analyst DATE 2-19-82

APPROVED BY Mark Freeman TITLE Assist. Admin. Analyst DATE FEB 20 1982

CONDITIONS OF APPROVAL, IF ANY: