

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. OIL CONS. COMMISSION
P.O. BOX 10
HOBBS, NEW MEXICO 88240
RECEIVED

UK 3
6-2176

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to ~~BUREAU OF LAND MANAGEMENT~~ reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well <input checked="" type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other	5. Lease Designation and Serial No. 0554858
2. Name of Operator Lynx Petroleum Consultants, Inc.	6. If Indian, Allottee or Tribe Name
3. Address and Telephone No. P.O. Box 1979 Hobbs, NM 88241 505-392-6950	7. If Unit or CA, Agreement Designation
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 1980' FNL & FEL Section 9, T-19S, R-35E	8. Well Name and No. Government "9" #1
	9. API Well No. 30-025-28157
	10. Field and Pool, or Exploratory Area Scharb Bone Springs
	11. County or Parish, State Lea, New Mexico

12. **CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other _____
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set a C.I.B.P. at 9450'.
2. Circulate hole with gelled brine mud.
3. Spot 10 sxs cement on top of C.I.B.P. at 9450'.
4. Spot 25 sxs cement 6850' - 7000'.
5. Spot 25 sxs cement 4020' - 4170'.
6. Spot 25 sxs cement 1525' - 1675'.
7. Spot 25 sxs cement 335' - 485'. TAG PLUG.
8. Spot 10 sxs cement surface plug.
9. Install dryhole marker and clean location.

14. I hereby certify that the foregoing is true and correct

Signed Mac Lwin

Title President

Date 6/18/96

(This space for Federal or State office use)

Approved by Salimah

Title Petroleum Engineer

Date 7/19/96

Conditions of approval, if any:

- SEE ATTACHED -