

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-28257
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	LG 740-3

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Lease Name or Unit Agreement Name Vacuum State
2. Name of Operator YATES PETROLEUM CORPORATION	8. Well No. 4
3. Address of Operator 105 South 4th St., Artesia, NM 88210	9. Pool name or Wildcat Scharb Bone Springs

4. Well Location Unit Letter <u>I</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>660</u> Feet From The <u>East</u> Line Section <u>4</u> Township <u>19S</u> Range <u>35E</u> NMPM <u>Lea</u> County
--

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER: <input type="checkbox"/>	SUBSEQUENT REPORT OF: REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows:

1. Pull Baker Model "R" packer at 9300'.
2. Set CIBP at 9400' to cover Bone Springs perforations 9452-9566'. Cap with 35' of cement.
3. Freepoint 5-1/2" casing, cut and pull. Expect to pull from 4100' based on well file data showing top of cement at 4200'.
4. GIH w/tubing to 50' inside 5-1/2" stub or 4100' whichever is deeper and spot 75 sack plug. Tag at 50' above 5-1/2" stub or 3900' whichever is higher. NOTE: 8-5/8" casing set at 4000' and circulated.
5. Spot 50 sack plug across 13-3/8" casing shoe at 491'. NOTE: 13-3/8" circulated.
6. Set 15 sack plug at surface. Install regulation abandonment marker.

NOTE: 25#/barrel salt gel mud will be placed between all plugs.
NOTE: NOTIFY NMOCD (393-6161) 24 HOURS PRIOR TO COMMENCING OPERATIONS.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE June 17, 1993

TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use)

ORIGINAL SIGNED BY MERRY SEXTON

APPROVED BY DATE JUN 22 1993

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JUN 21 1993

U.S. AIR FORCE