

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.B.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. LG-740

<p>SUNDRY NOTICES AND REPORTS ON WELLS <small>DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.</small></p>	
1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- P&A	7. Unit Agreement Name
2. Name of Operator Mesa Petroleum Co.	8. Farm or Lease Name Vacuum State
3. Address of Operator P. O. Box 2009 / Amarillo, Texas 79189	9. Well No. 5
4. Location of Well UNIT LETTER <u>E</u> <u>1980</u> FEET FROM THE <u>north</u> LINE AND <u>660</u> FEET FROM THE <u>west</u> LINE, SECTION <u>3</u> TOWNSHIP <u>19S</u> RANGE <u>35E</u> NMPM.	10. Field and Pool, or Wildcat Undes. Scharb-Wolfcamp
15. Elevation (Show whether DF, RT, GR, etc.) 3885.9' GR	12. County Lea

<p>16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:</p>		<p>SUBSEQUENT REPORT OF:</p>	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to P&A well as follows:

Set CIBP @ 8100' plus 35' of cement on top.
 Load hole with 9 ppg mud laden fluid w/ 10#/bbl SW gel.
 Cut off 5 1/2" csg @ approximately 7950'.
 Set 25 sx "C" 50' in and out of 5 1/2" csg stub.
 Set 25 sx "C" from 5900' to 5800' (base of San Andres).
 Set 25 sx "C" from 4050' to 3950' (8 5/8" csg shoe).
 Set 25 sx "C" from 1900' to 1800' (top of Salt).
 Set 25 sx "C" from 530' to 430' (13 3/8" csg shoe).
 Set 10 sx "C" from 100' to surface.
 Install dry hole marker.

XC: NMOC-D-H(O+2), CEN RCDS, ACCTG, MAT CONT, OPS(FILE), ROSWELL, MIDLAND, PARTNERS

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED William R. Kuntzsch TITLE SR DRILLING ENGINEER DATE 11/7/83
 ORIGINAL SIGNED BY JERRY SEXTON
 APPROVED BY DISTRICT SUPERVISOR TITLE _____ DATE NOV 9 1983
 CONDITIONS OF APPROVAL, IF ANY: