

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. <b>30-025-31438</b>
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Anschultz - Arco
8. Well No. 1
9. Pool name or Wildcat Knowles Devonian

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Rand Oil & Gas Company	
3. Address of Operator 1110 N. Big Spring, Midland, TX 79701	
4. Well Location Unit Letter <u>K</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>18</u> Township <u>17 S</u> Range <u>39E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) <u>3662.0' GR</u>	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) RU well service unit & pull out of hole w/tubing.
- 2) Set 5-1/2" CIBP on wireline @ 12,100' w/35' cement.
- 3) Set 5-1/2" CIBP on wireline @ 9280' w/35' cement.
- 4) Cut 5-1/2" @  $\pm 7000'$  and recover.
- 5) Set cement plug 50' in and 50' out of stub @ 7000'. (Note: If 5-1/2" cannot be recovered to 7000', a 100' plug will be set in the casing and a plug set 50' in and 50' out of stub, wherever that might be.)
- 6) Set cement plug 50' in and 50' out of 8-5/8" casing @ 4903'.
- 7) Set 100' plug @ 2340'.
- 8) Cut off casing head and set 10' plug @ surface.
- 9) Install permanent location marker.
- 10) Clear location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE AGENT DATE 6-9-94

TYPE OR PRINT NAME O. H. ROUTH (J. W. MULLOY ASSOCIATES, Inc.) TELEPHONE NO. 915-687-03

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

JUN 13 1994

RECEIVED

JUN 10 1991

SECURITY  
OFFICE