

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-31438
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Lease Name or Unit Agreement Name Anschultz - Arco
2. Name of Operator Rand Oil & Gas Company	8. Well No. 1
3. Address of Operator 1110 N. Big Spring, Midland, TX	9. Pool name or Wildcat Knowles Devonian
4. Well Location Unit Letter <u>K</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>18</u> Township <u>17S</u> Range <u>39E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) RU well service unit & POH w/tbg.
- 2) Run Cmt Bond Log & Perforate 9324'-9342' (37 holes).
- 3) RIH w/RBP & set @ 9497' & set packer @ 9179'.
- 4) Acidize w/2000 gal NEFE acid.
- 5) Swab 220 bbls water w/fluid level constant @1200'.
- 6) Release packer pick up RBP & POH.
- 7) Perforate 9307'-9311' (9 holes).
- 8) RIH & set RBP @ 9318' & packer @ 9253'.
- 9) Acidize 1000 gal NEFE acid.
- 10) Swab 99% water & 1% B.S.
- 11) Retrieve RBP & POH w/RBP & packer.
- 12) RIH w/285 jts & SN.
- 13) Shut well in.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jeff Rand TITLE President DATE 4/11/94

TYPE OR PRINT NAME Jeff Rand TELEPHONE NO. 214 788-4962

(This space for State Use)

APPROVED BY _____ TITLE ORIGINAL SIGNED BY JERRY SEXTON DATE APR 18 1994

CONDITIONS OF APPROVAL, IF ANY: _____