

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-32040
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Lease Name or Unit Agreement Name AMOCO-COM
2. Name of Operator RAND OIL & GAS, INC.	8. Well No. 1
3. Address of Operator 1110 N. BIG SPRING, MIDLAND, TX 79701	9. Pool name or Wildcat SOUTH KNOWLES (DEVONIAN)
4. Well Location Unit Letter H : 1980 Feet From The NORTH Line and 660 Feet From The EAST Line Section 12 Township 17-S Range 38-E NMPM LEA County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3673.4' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. RU well service unit & POH w/tubing.
2. Set 5-1/2" CIBP on wireline @ 12,100' w/35' cement.
3. Set 5-1/2" CIBP on wireline @ 9,280' w/35' cement.
4. Cut 5-1/2" casing @ ±7000' and recover.
5. Set cement plug 50' in and 50' out of 5-1/2" stub. (Note: If 5-1/2" cannot be recovered @ 7000', a 100' plug will be set in casing and a plug set 50' in and 50' out of 5-1/2" stub.
6. Set cement plug 50' in & out of 8-5/8" csg seat @ 4950'.
7. Set 100' plug @ 2340'.
8. Cut off csg head and set 10" cement plug @ surface.
9. Install permanent location marker.
10. Clear location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE AGENT DATE 6-9-94

TYPE OR PRINT NAME O. H. ROUTH (J. W. MULLOY ASSOCIATES, INC.) TELEPHONE NO. 915-687-03

(This space for State Use)

APPROVED BY [Signature] TITLE FIELD REPRESENTATIVE II DATE 7-12-94

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JAN 11 1994

JOHN HOOBS  
OFFICE