

STAPLIN ST A/C 1 # 6  
RECOMPLETION PROCEDURE

- 1: MIRU
- 2: Pull Rods & Pump
- 3: Install BOP
- 4: Pooh W/Tbg & TAC
- 5: Test POB pipe and blind rams to 2500 PSI
- 6: RIH W/Bit, collars and Tbg.
- 7: Drill out CIBP @ 10,022'.
- 8: Perforate Upper Penn 10,040-10,052 W/ 2 JSPF and the Abo 8,950-9,300 selectively with 2 JSPF.
- 9: RIH W/treating Pkr and RBP on 2 7/8" Tbg. Set REP @ 9350 and pressure test to 2500 PSI.
- 10: Set Pkr above Abo perfs. Acidized Abo as per service Co. recommendation. Swab test the Abo Perfs.
- 11: Release Pkr, retrieve RBP and POOH. RIH W/production tbg. Remove BOP. NU wellhead. RIH with Rods and pump.
- 12: Hang well off and turn to test.

**RECEIVED**

12 1994

TO HOBBS  
OFFICE