

DISTRICT I

P.O. Box 1980, Hobbs, NM 88240

DISTRICT II

P.O. Box Drawer DD, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**

P.O. Box 2088

Santa Fe, New Mexico 87504-2088

WELL API NO.

30-025-33765

5. Indicate Type of Lease

STATE ☐

FEE ☐

6. State Oil / Gas Lease No.

B-1030

**SUNDRY NOTICES AND REPORTS ON WELL**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT  
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

WEST VACUUM UNIT

1. Type of Well: OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator  
TEXACO EXPLORATION & PRODUCTION INC.

8. Well No.  
60

3. Address of Operator  
205 E. Bender, HOBBS, NM 88240

9. Pool Name or Wildcat  
VACUUM GRAYBURG SAN ANDRES

4. Well Location  
Unit Letter I : 2470 Feet From The SOUTH Line and 1100 Feet From The EAST Line  
Section 34 Township 17-S Range 34-E NMPM LEA COUNTY

10. Elevation (Show whether DF, RKB, RT,GR, etc.) 4030' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPERATION ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1) MIRU pulling unit, pull rods and pump, install BOP, unseat tbg anchor and TOH with tbg.

2) Drill out CIBP @ 4765' and clean out to 4850.

3) Set RBP @ +/- 4830', Pkr @ +/- 4610 and acidize lower SA with 4000 gals 15% NEFE and 3000# rock salt @ 4-5 BPM and max. pressure of 4000 psig.

4) Move up hole, set RBP @ +/- 4610', Pkr @ +/- 4400' and acidize upper SA with 4000 gals 15% NEFE and 3000# rocksalt.

5) Release Pkr and TOH with RBP, Pkr and workstring. Swab well untill pH is between 6-7.

6) Pump 3 drums c: TH-756 inhibitor mixed in 30 bbls of FW across perms 4494-4816'.

7) Run production equipment and place the well on test.

I hereby certify that the information above is true and complete to the best of my knowledge and belief

SIGNATURE Monte C. Duncan TITLE Engr Asst

DATE 9/8/97

TYPE OR PRINT NAME Monte C. Duncan

Telephone No 397-0418

(This space for State Use)

Orig. Signed by  
Paul Reutz  
Geologist

APPROVED BY Paul Reutz TITLE Geologist

DATE

CONDITIONS OF APPROVAL, IF ANY:

**OCT 06 1997**