

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIP
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

NM 05148

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Water Injection Well	7. UNIT AGREEMENT NAME Teas Yates Unit
2. NAME OF OPERATOR Anadarko Production Company	8. FARM OR LEASE NAME Tract #13
3. ADDRESS OF OPERATOR P.O. Box 806 Eunice, New Mexico 88231	9. WELL NO. 1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660' FSL & 660' FWL Sec 11, T 20S, R 33E	10. FIELD AND POOL, OR WILDCAT Teas Yates
14. PERMIT NO.	11. SEC., T. R., M., OR BLK. AND SURVEY OR AREA 11-20S-33E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3540' GR	12. COUNTY OR PARISH Lea
	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting and proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. RUPU. TOH w/2-3/8" PVC lined injection tbg.
2. TIH w/2-3/8" regular shoe on 500' of 2-3/8" drill collars & 2-3/8" tbg.
3. CO to TD 3482'.
4. Set one continuous cement plug from TD 3482' to 900'.
5. Mud up inside 5 1/2" csg w/22 bbls of 10# brine & 8 sx brine gel.
6. Set 10 sx cement plug @surface & plugged hole marker.
7. RDPV.
8. Clean up location & re-claim in accordance w/BLM instructions.

* Perforate at 850' establish circulation and squeeze with sufficient volume of cement to reach the surface.

18. I hereby certify that the foregoing is true and correct

SIGNED

John C. English

TITLE

Area Supervisor

DATE

Sept 9, 1981

(This space for Federal or State Approval)

APPROVED BY (Orig. Sgd.) PETER W. CHESTER TITLE


CONDITIONS OF APPROVAL, IF ANY:

DATE

SEP 14 1981

FOR

JAMES A. GILLHAM See Instructions on Reverse Side
DISTRICT SUPERVISOR



1912
JAN 12
1912

1912

1912

1912

1912