

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIP  
(Other instruction  
verse side)

Form approved.  
Budget Bureau No. 42-31424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. NM-02127-B	
2. NAME OF OPERATOR Marathon Oil Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P. O. Box 2409, Hobbs, New Mexico 88240		7. UNIT AGREEMENT NAME Lea Unit	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface  1980' FSL and 660' FWL		8. FARM OR LEASE NAME Lea Unit	
14. PERMIT NO.		9. WELL NO. 1	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) DF 3674'		10. FIELD AND POOL OF WELL Lea Devonian	
		11. SEC., T., R., M., OR BLM., AND SURVEY OR AREA Sec. 12-20S-34E	
		12. COUNTY OR PARISH Lea	
		13. STATE N.M.	

18. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	
(Other) Plug and Abandon <input checked="" type="checkbox"/>		(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Abandon well by cementing from below reef to surface using the following procedures:

1. Go in hole with open ended tubing to approximately 1800'.
2. Flush hole with 40 barrels of fresh water.
3. After flush, pump approximately 2200 sacks of Class "C" cement and pull tubing. Let set for 24 hours.
4. Go back in hole and tag cement. From this tag, compute volume of cement needed for fillup of well.
5. Pump needed volume of Class "C" cement to finish plugging of well.
6. Erect plug and abandon marker.
7. Clean up location.

18. I hereby certify that the foregoing is true and correct

SIGNED

*Alfred L. Davis*

TITLE

Production Engineer

DATE

November 1, 1977

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE