

UNITED STATES DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY  
N. M. OIL CONS. COMMISSION  
P.O. BOX 1960  
HOBBS, NEW MEXICO 88240

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☐ other ☐ Water Disposal

2. NAME OF OPERATOR  
TEXACO Inc.

3. ADDRESS OF OPERATOR  
P.O. Box 728, Hobbs, New Mexico 88240

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 1980' FNL & 1980' FEL  
AT TOP PROD. INTERVAL: (Unit Letter G)  
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>		<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>		<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>		<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>		<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>		<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>		<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>		<input type="checkbox"/>
(other)			

5. LEASE  
LC-029519 (a)

6. IF INDIAN, ALLOTTEE OR TR BE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
B.V. Lynch "A"

9. WELL NO.  
11

10. FIELD OR WILDCAT NAME  
Lynch Yates 7-Rivers

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec. 34, T-20-S, R-34-E

12. COUNTY OR PARISH  
Lea

13. STATE  
NM

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)  
3732' (DF)

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Rig up.
2. Set pkr @ 3150'. Cement squeeze below pkr. w/400 sx Class H cement.
3. Spot 20 sx cement plug from 3150'-3050'.
4. Spot 20 sx cement plug from 1670'-1570'.
5. Spot 20 sx cement plug from 100'-surface.
6. Install dry hole marker. Clean location.
7. Abandon well.

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED W. B. L. TITLE Dist. Opr. Mgr. DATE 5/30/85

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE 11-5-85  
CONDITIONS OF APPROVAL, IF ANY:

**Subject to  
Like Approval  
by State**

\*See Instructions on Reverse Side