Submit 3 Copies To Appropriate District State of New Mexico Form C-103 Office Energy, Minerals and Natural Resources Revised March 25, 1999 District I WELL API NO. 1625 N. French Dr., Hobbs, NM 88240 District II 30-025-04102 OIL CONSERVATION DIVISION 1301 W. Grand Ave., Artesia, NM 88210 5. Indicate Type of Lease District III 1220 South St. Francis Dr. STATE 🖂 FEE 1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505 District IV State Oil & Gas Lease No. 1220 S. St. Francis Dr., Santa Fe, NM 015264 SUNDRY NOTICES AND REPORTS ON WELLS 7. Lease Name or Unit Agreement Name: (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH Northwest Eumont Unit PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other Rhombus Operating Co., Ltd. Name of Operator 8. Well No. #159 Address of Operator 9. Pool name or Wildcat P.O. Box 8316, Midland, Texas 79708-8316 **Eumont Yates** Well Location 1,980 feet from the South Unit Letter K: 1,980 line and feet from the West Section 34 Township 19-\$ Range 36-E **NMPM** County Lea 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 3,626' GL 11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WORK ALTERING CASING [] **TEMPORARILY ABANDON CHANGE PLANS** COMMENCE DRILLING OPNS. PLUG AND **ABANDONMENT** PULL OR ALTER CASING **MULTIPLE** CASING TEST AND  $\Box$ COMPLETION **CEMENT JOB** OTHER: OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. Surface casing: 9-5/8" @ 317', cmt circulated Production csg: 7" 23#, TOC 1,925' T.S., holes in casing 501 – 800' Openhole: 3,800 - 3,940Tubing/packer: TA'd w/ RBP @ 3,750' (1991) 1. Dig & line earthen work pit, flow well down as needed. MIRU. NU BOP. 2. RIH w/ tbg to 3,750' and circulate hole w/ mud, pump 25 sx C cmt on RBP @ 3,750'. 3. POOH w/ tbg to 2,800' and pump 25 sx C cmt 2,800 - 2,700'. base of salt plug 4. RIH w/ wireline and perforate casing @ 1,500'. 5. RIH w/ AD-1 packer to 1,300' and squeeze 50 sx C cmt 1,500 – 1,400'. top of salt plug RIH w/ wireline and perforate casing @ 367'. POOH w/ AD-1 packer to 200' and squeeze 75 sx C cmt 367 - 267'. WOC & TAG surface casing shoe plug Pump 10 sx C cmt 50' to surface. surface plug Cut off wellhead and install dryhole marker. Cut off anchors and level location. I hereby certify that the information above is true and complete to the best of my knowledge and belief. SIGNATURE TITLE Engineer DATE 09/06/02 Type or print name James F. Newman, P.E. Triple N Services, Inc. Telephone No. 915-687-1994 (This space for State use) Chadinal Signature GARY W. WINK DASEP 1 1 2997 APPPROVED BY APPPROVED BY SART WHAT A CONDITION OF APPROVED BY CONDITION OF APPROVED HOURS PRIOR TO THE BEGINNING OF PLUGGING OFFICE ONS FURTHE CARDS

TO BE APPROVED,