

Submit 3 Copies To Appropriate District Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

1301 W. Grand Ave., Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

WELL API NO.

30-025-04107

5. Indicate Type of Lease

STATE ☐ FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name:

Northwest Eumont Unit

8. Well No. **#150**

9. Pool name or Wildcat
Eumont Yates

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator **Rhombus Operating Co., Ltd.**

3. Address of Operator

200 N. Lorraine, Suite 1270, Midland, Texas 79711

4. Well Location

Unit Letter **D** : **660** feet from the **North** line and **660** feet from the **West** line

Section **34** Township **19-S** Range **36-E** NMPM County **Lea**

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Surface casing: 9-5/8" @ 338', cmt'd circulated

Production csg: 7" 20#, TOC 1,675' by TS. Sqz'd csg leak 971 - 1,002' w/ 100 sx in 1990.

Perforations: openhole 3,860 - 4,000'

Tubing/packer: tbg & rods @ +/- 3,940'

1. Dig & line earthen work pit, flow well down as needed. MIRU. POOH w/ rods and pump.

2. NU BOP and POOH w/ tbg.

3. RIH w/ tbg to 3,810' and circulate hole w/ mud, pump 25 sx C cmt w/ 2% CaCl₂ @ 3,810'. WOC & TAG.

4. POOH w/ tbg to 2,800' and pump 25 sx C cmt 2,800 - 2,700'. **base of salt plug**

5. POOH w/ tbg to 1,000' and pump 25 sx C cmt 1,000 - 900'. **top of salt plug**

6. Perforate casing @ 388'. RIH w/ packer to 90' and squeeze 50 sx C cmt w/ 2% CaCl₂ 388 - 288'. WOC & TAG **surface casing shoe & freshwater plug**

7. Pump 10 sx C cmt 50' to surface. **surface plug**


8. Cut off wellhead and install dryhole marker. Cut off anchors and level location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE  TITLE **Engineer** DATE **07/23/02**

Type or print name **James F. Newman, P.E.** Triple N Services, Inc. Telephone No. **915-687-1994**
(This space for State use)

APPROVED BY  ORIGINAL SIGNED BY GARY W. WINK
CUREL REPRESENTATIVE II/STAFF MANAGER DATE **AUG 09 2002**

Conditions of approval, if any: