

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B154

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Amerada Hess Corporation	8. Farm or Lease Name State "D"
3. Address of Operator Drawer "D", Monument, New Mexico	9. Well No. 2
4. Location of Well UNIT LETTER E 1980 FEET FROM THE North LINE AND 660 FEET FROM West LINE, SECTION 1 TOWNSHIP 20-S RANGE 36-E NMPM.	10. Field and Pool, or Wildcat Eunice-Monument (G/SA)
15. Elevation (Show whether DF, RT, GR, etc.) 3586' DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to pull rods, pump and tubing. Perforate 4-1/2" liner opposite Garyburg San Andres zone selectively fr. 3727' - 3729', 3727' - 3741', 3785' - 3787', 3795' - 3799', 3811', 3818' - 3820' and 3827' - 3829' with 2 SPF. Run 4-1/2" packer and plug at 3835' and 3890'. Swab. Acidize with 1000 gallons 15% NE-FE HCL acid. Flush to bottom of perfs with 24 barrels NE-FE HCL acid. Flush to bottom of perfs with 24 barrels NE-FE HCL acid. Swab load. Pull packer and plug at 3700' and 3835'. Acidize with 1000 gallons 15% NE-FE HCL acid. Swab load. Pull plug, packer and tubing. Run tubing, pump and rods. Chemical squeeze and resume production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED EB Zikes TITLE Supv. Adm. Ser. DATE 1/23/81

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: