Form 9-331
(May 1963)

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other Instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

. . . . . (a)

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

1.

OIL WELL [X]   GAS WELL [ ]   OTHER

7. UNIT AGREEMENT NAME

2. NAME OF OPERATOR

Continental Oil Company

8. FARM OR LEASE NAME

Reed Sanderson Unit

3. ADDRESS OF OPERATOR

P. O. Box 460, Hobbs, New Mexico 88240

9. WELL NO.

. .

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' FSL & 1980' FWL, Section 3, T-20, A-36E,
Lea County, New Mexico.

10. FIELD AND POOL, OR WILDCAT

Eumont Pool

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 3, T-20S, R-36E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3626' D.F.

12. COUNTY OR PARISH | 13. STATE

Lea | N.M.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF [ ]	PULL OR ALTER CASING [ ]	WATER SHUT-OFF [ ]	REPAIRING WELL [ ]
FRACTURE TREAT [ ]	MULTIPLE COMPLETE [ ]	FRACTURE TREATMENT [ ]	ALTERING CASING [ ]
SHOOT OR ACIDIZE [ ]	ABANDON* [ ]	SHOOTING OR ACIDIZING [ ]	ABANDONMENT* [ ]
REPAIR WELL [ ]	CHANGE PLANS [ ]	(Other)	
(Other) Convert to Water Inj. [X]		(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

In connection with the Reed Sanderson Unit Waterflood, it is proposed to convert the subject well to water injection using the following procedure:

1. Tag bottom with tubing and tally out.
2. Run cement-lined tubing w/packer to be set at approximately 3700'.
3. Connect well up and commence water injection down tubing.

NMOCC Order R-3131 was issued on September 28, 1966, authorizing institution of the Reed Sanderson Unit Waterflood.

A subsequent report will be submitted upon completion of this work.

18. I hereby certify that the foregoing is true and correct

SIGNED _____   TITLE Supervising Engineer   DATE 5-5-67

(This space for Federal or State office use)

APPROVED BY _____   TITLE _____   DATE _____

CONDITIONS OF APPROVAL, IF ANY:

USGS-5   ATL-Ros-2   CHEV-Mid-2   PAN AM-Hobbs-2   FILE

*See Instructions on Reverse Side