

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SALE PRICE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REOPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT TO DRILL C-101 FOR SUCH PROPOSALS.)</small></p>		<p>5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/></p> <p>5. State Oil & Gas Lease No.</p>
<p>1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER</p> <p>2. Name of Operator GULF OIL CORPORATION</p> <p>3. Address of Operator P. O. Box 670, Hobbs, NM 88240</p> <p>4. Location of Well UNIT LETTER D 660 FEET FROM THE North LINE AND 660 FEET FROM West THE LINE, SECTION 28 TOWNSHIP 19S RANGE 37E N.M.P.M.</p>		<p>7. Unit Agreement Name</p> <p>8. Farm or Lease Name F. W. Kutter (NCT-B)</p> <p>9. Well No. 3</p> <p>10. Field and Pool, or Wildcat Eunice Monument</p>
<p>15. Elevation (Show whether DF, RT, CR, etc.) 3654' GL</p>		<p>12. County Lea</p>

<p>16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data</p>			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1903.

3978' TD.

Pull producing equipment. Set at CIBP at 3600'. Cap with 35' cement. Set a cement retainer at approximately 2300'. Cap with 15 sxs cement. Spot abandonment mud up to 50'. Spot 50' cement plug from 50' to surface. Install dry hole marker. Clean & clear location.

I, Thereby certify that the information above is true and complete to the best of my knowledge and belief.

<p>CRD. <u>W. B. Sikes, Jr.</u></p> <p>ORIG. SIGNED BY <u>John Runyan</u></p> <p>APPROVED BY <u>Geologist</u></p> <p>CONDITIONS OF APPROVAL, IF ANY:</p>	<p>TITLE <u>Area Engineer</u></p> <p>TITLE</p>	<p>DATE <u>5-3-78</u></p> <p>DATE <u>MAY 4 1978</u></p>
--	--	---

Exposure 11/10/78