

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT..." (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator ARCO Oil & Gas Company Division of Atlantic Richfield Company	8. Farm or Lease Name James H. Williams
3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER A 330 North 330 EAST 33 LINE, SECTION 19S RANGE 37E TOWNSHIP NMPM.	10. Field and Pool, or Wildcat Eunice Monument Grbg SA
15. Elevation (Show whether DF, RT, GR, etc.) 3587' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to P & A in the following manner:

1. Rig up, install BOP. POH w/ comp assy.
2. RIH w/ 7" cmt retr set retr @ 3700'. Pump 35 sx Cl "C" cmt w/ 2% CaCl<sub>2</sub> & 4% gel into OH. Spot 35' cmt on top of retr.
3. Run CBL. Perf 7" csg above TOC as indicated by log.
4. RIH w/ cmt retr, set retr above squeeze perfs & pump Cl "C" cmt behind 7" csg to surf. Spot 6 sx cmt on top of retr.
5. Spot 100' Cl "C" cmt inside 7" csg 1500-1600'. Spot heavy gelled mud between all cmt plugs.
6. Spot 10 sx Cl "C" cmt @ surf, install regulation dry hole marker, clean & level location.

THE COMPLETION MUST BE NOTIFIED 24  
HOURS BEFORE THE COMPLETION OF  
PLUG AND ABANDONMENT FOR THE C-103  
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>D.D. McDaniel</u>	TITLE <u>Dist. Drlg. Supt.</u>	DATE <u>8/11/80</u>
APPROVED BY <u>Jerry Sexton</u>	TITLE <u></u>	DATE <u>AUG 15 1980</u>
CONDITIONS OF APPROVAL <u>Dist. Drlg. Supt.</u>		