

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

N.M. OIL CONS. COMMISSION  
P.O. BOX 1980  
HOBBS, NEW MEXICO 88240

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Doyle Hartman, Oil Operator

3. Address and Telephone No.

P.O. Box 10426 Midland, Tx 79701 (915) 684-4011

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FNL & 1650' FWL  
Section 8 T-20-S, R-37-E

5. Lease Designation and Serial No.

LC-031621B

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Britt "B-8" No. 3

9. API Well No.

30-025-06008

10. Field and Pool, or Exploratory Area

Monument Paddock

11. County or Parish, State

Lea County, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_
- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Spot cement plug from PBTD 5244' up to 4000' and tag top of plug.
2. Run and set retainer at 3000' and squeeze hole in casing 3279' to 3780' with 200 sx cement.
3. Load hole with 9.5# mud.
4. ~~Spot cement plug 3' to 70'.~~
5. Cap well with dry hole marker.
6. Rig down and clean location.

Replace No. 4 as follows:

Perf 5 1/2" csg @ 632' & squeeze cement outside 5 1/2" & fill inside to surface.

14. I hereby certify that the foregoing is true and correct

Signed

Title Production Supervisor

Date 3-23-94

(This space for Federal or State office use)

Approved by **(ORIG. SGD.) JOE G. LARA**  
Conditions of approval, if any:

Title **PETROLEUM ENGINEER**

Date 4/7/94