Attachment C-102 Gulf Oil Corporation, Bertie Whitmire # 5, section 8, 20-S, 37-E

- 6. Run Baker retrievable BP and FB packer on tubing and straddle new perfs 5575-5625'. Swab and test natural. If warranted, treat new perfs with 15% NEA and 7/8" RCNB sealers. Swab and test.
- 7. Full straddle tools then rerun tabing, rods and pump. Test, then return well to production.

- an bar 1996 Santan Andrea, an ann an Anna an 1996 Anna an A