

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company		8. Farm or Lease Name Bertha J. Barber
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201		9. Well No. 15
4. Location of Well UNIT LETTER D 660 FEET FROM THE North LINE AND 330 FEET FROM THE West LINE, SECTION 8 TOWNSHIP 20-S RANGE 37-E NMPM.		10. Field and Pool, or Wildcat Monument-Paddock
15. Elevation (Show whether DF, RT, GR, etc.) 3559' GR		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well presently produces 1/2 BOPD + 24 BWPD from Paddock perfs 5146-5164' & 5170-5200'. No remedial or recompletion possibilities exist. We propose to P & A as follows.

1. Load hole w/salt gel mud containing 25 sx gel/100 BW.
2. Spot 30 sk cement plug from 5010-5140'.
3. Shoot off & pull 7" casing from free point (TOC @ 3980'.)
4. Spot 40 sx cement (112' long plug) in & out of 7" stub.
5. Cut 9-5/8" casing @ 950' and pull.
6. Spot 75 sx cement from 900' to 1000' (13-3/8" shoe @ 948')
7. Place 10 sx cement in top of well & erect dry hole marker.

13-3/8" casing will remain intact. Location will be cleared & levelled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *D.D. Dutcher* TITLE Dist. Drlg. Supervisor DATE 3/24/72

APPROVED BY Orig. Signed by John Runyan TITLE Geologist DATE MAR 29 1972
CONDITIONS OF APPROVAL, IF ANY: