

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-7

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
A-1212

SUNDRY NOTICES AND REPORTS ON WELLS
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REPERF OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT TO DRILL (FORM C-101) FOR SUCH PROPOSALS.

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER - Injection	7. Unit Agreement Name
2. Name of Operator Amoco Production Company	8. Farm or Lease Name South Hobbs (GSA) Unit
3. Address of Operator P. O. Box 68, Hobbs, New Mexico 88240	9. Unit No. 45
4. Location of well UNIT LETTER I 1980 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 4 TOWNSHIP 19-S RANGE 38-E N.M.P.M.	10. Field and Pool, or adjacent Hobbs GSA
11. Elevation (Show whether DF, RT, GR, etc.) 3614' DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposals or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to squeeze off zone I, deepen well to oil/water contact, perforate zone II, and acidize zones II and III as follows:

Release the packer and pull tubing. Plug back to 4066' and 10/20 mesh sand. Cap with 5' of Calseal. Set a cement retainer at apx. 4030'. Cement squeeze with 50 sacks class "C" neat cement followed by 200 sacks class "C" with 5#/sack Gilsonite. Tail in with 200 sacks class "C" neat cement. Reverse out excess cement. Drill out to 4231'. Perforate 4088'-4114' with 2 SPF. Acidize with 3800 gal 15% NE HCL containing 1 gal/1000 gal of corrosion inhibitor. Flush with injection water. Pull the packer. Set a retrievable bridge plug at apx. 4121' and a packer at apx. 4069'. Acidize with 1800 gal 15% NE HCL containing 1 gal/1000 gal corrosion inhibitor. Flush with injection water. Pull the packer and the bridge plug. Run tubing and packer. Set the packer at apx. 3821'. Return well to injection.

0+5-NMOCD,H 1-HOU 1-SUSP 1-CLF

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cathy L. Ferman TITLE Assist. Admin. Analyst DATE 3-4-83

APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON TITLE DISTRICT SUPERVISOR DATE MAR 8 1983
CONDITIONS OF APPROVAL, IF ANY: