| f | 1 | | |
|---|--|--|---|
| COPIES RECEIVED | | | Form C-103 |
| TRIBUTION | | | Supersedes Old C-102 and C-103 |
| FE FE | NEW MEXICO OIL CONS | ERVATION COMMISSION | Effective 1-1-65 |
| FILE | | | |
| U.S.G.S. |] | | 5a. Indicate Type of Lease |
| LAND OFFICE | | | State Fee 🗙 |
| OPERATOR | | | 5. State Oil & Gas Lease No. |
| | | | 8490 |
| SUNDE (DO NOT USE THIS FORM FOR PRI USE "APPLICAT | AND TICES AND REPORTS ON OPDSALS TO DRILL OR TO DEEPEN OR PLUG B | WELLS DACK TO A DIFFERENT RESERVOIR. H PROPOSALS.) | |
| 1. | | | 7. Unit Agreement Name |
| WELL GAS WELL | OTHER- | | |
| 2. Name of Operator | | and a second | 8. Farm or Lease Name |
| SUN OIL COMPANY | | | H.D. McKinley |
| 3. Address of Operator | | | 9. Well No. |
| P.O. BOX 1 | 861, Midland, Texas 797 | 701 | 5 |
| 4. Location of Well | | | 10. Field and Pool, or Wildcat |
| UNIT LETTERB, | 610 FEET FROM THE North | LINE AND 1980 FEET FROM | Byers - Wueen |
| Fact | 5 100 | 207 | 777777777777777777777777777777777777777 |
| THE LINE, SECTI | ON 5 TOWNSHIP 198 | RANGE ЗВЕ NИРМ | χ |
| | 15. Elevation (Show whether | DE PT CP | <u> </u> |
| | | | 12. County |
| | | GR. | |
| Check | Appropriate Box To Indicate N | ature of Notice, Report or Ot | her Data |
| NOTICE OF 1 | TENTION TO: | SUBSEQUEN | REPORT OF: |
| — –– | | | |
| PERFORM REMEDIAL WORK | PLUG AND ABANDON | REMEDIAL WORK | ALTERING CASING |
| TEMPORARILY ABANDON | | COMMENCE DRILLING OPNS. | PLUG AND ABANDONMENT |
| PULL OR ALTER CASING | CHANGE PLANS | CASING TEST AND CEMENT JOB | |
| | | OTHER | |
| OTHER | | | |
| | | | |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1-21-74 Move in and rig up

- 1-22-74 Circulate hole with mud laden fluid, pump 45 sack plug from 3775' Pull Tubing.
- 1-23-74 Break down well head, weld on pull nipple, shot casing @ 1031' Pull & lay down 7" casing. Rig up to run 2-3/8 tubing.
- 1-24-74 Run tubing to 1063' and pump a 30 sack plug, pull tubing to 340' and pump a 50 sack plug across 9-5/8 casing shoe. Pull tubing to 30' and pump a 15 sack top plug, rig down and move off.

Weld on cap & install permanent marker.

| 18. I hereby certify that the Inf SIGNED | DDC | e to the best of my knowledge and belief. | DATE 1-28-74 |
|---|---------|---|--------------|
| APPROVED BY CONDITIONS OF APPROVAL, | IF AFY: | TITLE | DATE |