

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ For ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. Name of Operator Amoco Production Company	7. Unit Agreement Name
2. Address of Operator P. O. Box 68, Hobbs, NM 88240	8. Farm or Lease Name South Hobbs (GSA) Unit
3. Location of Well UNIT LETTER <u>F</u> <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM THE <u>West</u> LINE, SECTION <u>15</u> TOWNSHIP <u>19</u> RANGE <u>38</u> NMPM.	9. Well No. 106
10. Field and Pool, or Wildcat Hobbs GSA	
11. Elevation (Show whether DF, RT, GR, etc.) 3603 DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
FULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to cement casing:

Pull tubing, rods, and pump. Run a retrievable bridge plug and set at 3950'. Cap with 15' of sand. Run a casing inspection log from 3950' to surface. Perforate casing at 1600' w/2 JSPF. Run tubing and packer. Set packer at 1580'. Squeeze annular space between 8-5/8" and 10-3/4" casings with 300 sacks of cement. If cement circulates to surface, close casing valve and squeeze cement downward across salt sections. Pull tubing. Run tubing collars & bit and drill out excess cement and retainer. Wash sand off bridge plug. Pull tubing, bit, collars, and retrievable bridge plug. Run production tubing, rods, and pump. Return to production.

0+4-NMOCD, H 1-Hou 1-Susp 1-CLF

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cathy L. Ferman TITLE Assist. Admin. Analyst DATE 9-28-81

APPROVED BY Jerry Sexton TITLE Dist 1, Supv. DATE SEP 30 1981

CONDITIONS OF APPROVAL, IF ANY: