

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-12466 ✓
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	B-1626-1
7. Lease Name or Unit Agreement Name	NORTH MONUMENT G/SA UNIT BLK. 14
8. Well No.	2
9. Pool name or Wildcat	EUNICE MONUMENT G/SA

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator AMERADA HESS CORPORATION
3. Address of Operator DRAWER D, MONUMENT, NEW MEXICO 88265	4. Well Location Unit Letter <u>B</u> : <u>660</u> Feet From The <u>NORTH</u> Line and <u>1980</u> Feet From The <u>EAST</u> Line

Section <u>36</u>	Township <u>19S</u>	Range <u>36E</u>	NMPM	LEA	County
10. Elevation (Show whether DF, RKB, RT, GR, etc.)					

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: CEMENT SQUEEZE. <input checked="" type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
NMGSAU WELL #1402

PLAN TO MIRU PULLING UNIT & INSTALL BOP. TIH W/6-5/8" RBP AND SET AT APPROXIMATELY 3700'. DUMP SAND ON TOP OF RBP. TEST PRODUCTION CASING. RU SCHLUMBERGER & RUN GR/CBL TO FIND TOP OF CEMENT BEHIND 6-5/8" CASING. PERFORATE CASING ABOVE TOP OF CEMENT TO WRAP UP CASING AND ELIMINATE GAS PRESSURE AT SURFACE. TIH W/PKR & SET ABOVE SQUEEZE HOLES. ESTABLISH CIRC. RATE THROUGH ANNULUS & OBTAIN A FLUID CALIPER FOR CEMENTING VOLUMES. TIH W/CEMENT RETAINER & SET 100' ABOVE SQUEEZE HOLES. CIRC. CEMENT TO SURFACE & SQUEEZE OFF HOLES. TIH W/A 5-7/8" BIT. DRILL OUT RETAINER & CEMENT & PRESSURE TEST CASING & BRADENHEAD. CIRC. SAND OFF OF RBP. TIH RETRIEVE RBP & TOH. TIH W/PRODUCTION EQUIPMENT AND RETURN WELL TO PRODUCTION.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE R. L. Wheeler Jr. TITLE SUPV. ADM. SVC. DATE 4-30-93

TYPE OR PRINT NAME R.L. WHEELER, JR. TELEPHONE NO. 393-2144

(This space for State Use)

ORIGINAL OWNED BY JERRY SEXTON
MAY 1993

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: