

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-B1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 0631

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal Lea

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Lea Bone Springs

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 11 T-20-S, R-34E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT--" for such proposals.)

1.

OIL WELL ☐ GAS WELL ☐ OTHER Oil well which was P & A 9-22-70

2. NAME OF OPERATOR

Edwin Foster Blair

3. ADDRESS OF OPERATOR

2215 Wilco Bldg., Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)

At surface

1900' FSL, 2060' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3653' KB

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐Replug well ☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

In a meeting 9-22-75 attended by Messrs. Brown, Coshow, and Sims with the USGS and Messrs. Hinson and Martin with NCRA, the following revised replugging procedure was mutually agreed upon:

1) Spot 150 sx cement plug at 8 5/8" casing stub at 2516'. Pull tubing up into 13 3/8" casing, pressure up to 500#, and shut-in overnight.

2) Tag cement plug, spot 75 sx. cement plug on top of above plug. Pull tubing, and pump 200 sx. cement into 13 3/8" casing, leaving 100 sx. inside 13 3/8" casing and 100 sx below casing shoe. Shut-in overnight.

3) Spot 50 sx. cement plug in top of surface casing.

18. I hereby certify that the foregoing is true and correct

SIGNED

B. J. Hinson

TITLE

Agent

DATE

9-24-75

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side