

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE\*  
(Other instructions on  
reverse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

131 03173

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Lea Penn Gas

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 3, 20-S, 34-E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

CREATHOUSE &amp; PIERCE

3. ADDRESS OF OPERATOR

204 VON TOWER BLDG., MIDLAND, TEXAS 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

660' FSL &amp; 1980' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3660' D.F.

16.

## Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☒CHANGE PLANS ☐

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☐(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

This well has been plugged back to 10,184' and tested salt water thru perforations 9833-9848'. It is proposed to plug and abandon the well as follows:

Pull 4½" casing from approx. 8000' and set 100' cement plug at top of 4½" stub.  
Set 100' cement plug in base of 9 5/8" casing at 5032'.  
Set cement plug at 3300-3400' in 9-5/8" casing to separate Base Salt and Top Yates.  
Pull 9 5/8" casing from approx. 1500' and set 100' cement plug at top of 9 5/8" stub.  
Set 50' cement plug in base of 13 3/8" casing at 512'.  
Set surface plug with 10 sxs. and install 4" pipe marker with company name and well location.  
Clean and level location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Engineer

DATE

10-18-71

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side

RECEIVED

Oct 2 1971

OIL CONSERVATION CO. AM.  
HOBBBS, N. M.