

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATION
(Other instructions on
reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

100 04060

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal /

9. WELL NO.

2-10

10. FIELD AND POOL, OR WILDCAT

Lee Farm Gas

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 10, 20-1, 34-E

12. COUNTY OR PARISH

Lee

13. STATE
New Mexico1. OIL WELL ☐ GAS WELL ☒ OTHER2. NAME OF OPERATOR
GREATHOUSE & SIBENCE3. ADDRESS OF OPERATOR
204 VAL TOWER BLDG., MIDLAND, TEXAS 797014. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660' PERM & 1990' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, CR, etc.)

3630' Grd.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well is plugged back to 13,140' and has been a gas producer from perforations 12,930-13,103' in Morrow formation. Gas production has ceased and bottom hole pressure tests indicate the zone is depleted. It is proposed to plug and abandon as follows:

Set cement plug in 4 1/2" csg. with 25 sacks at 12,500-12,800', and with 25 sacks at 10,000-10,300'.

Pull 4 1/2" csg. from approx. 7500' and set 100' cement plug at top of 4 1/2" stub.

Set 100' cement plug in base of 8 5/8" casing at 5250', and 100' cement plug at 3300-3400' in 8 5/8" casing.

Pull 8 5/8" casing from approx. 1500' and set 100' cement plug at top of 8 5/8" stub.

Set 50' cement plug in base of 13 3/8" casing at 520'.

Set surface plug with 10 sacks and install 4" pipe marker with company name and well location.

Clean and level location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

DATE

10-18-71

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

RECEIVED

NOV 2 1971

**OIL CONSERVATION COMM.
HOBBS, N. M.**