

# RE-ENTRY, CASING AND CEMENTING PROGRAM

- 1) Drill plug #1 - Surface plug using a 8 3/4" bit inside 9 5/8" casing.
- 2) Drill plug #2 - cement plug from 1315'-1415' inside 9 5/8" casing - 8 3/4" bit.
- 3) Drill plug #3 - cement plug from 2900'-3000' inside 9 5/8" casing - 8 3/4" bit.
- 4) Drill plug #4 - cement plug from 3786'-3886' inside 9 5/8" casing - 8 3/4" bit.
- 5) Tag 7" Stub at +/- 3836' - go inside with 7" w/ 6 1/4" bit.
- 6) Drill plug #5 - cement plug from 5424'-5575' inside 7" casing with 6 1/4" bit.
- 7) Drill plug #6 - cement plug from 7450'-7600' inside 7" casing w/ 6 1/4" bit.
- 8) Run cased hole TDT Log to determine the productivity of the Delaware Mountain Sand Formation.
- 9) If productive tie back 7" casing to surface with a bowl over - overshot. The 7" casing will not be cemented.
- 10) If non-productive then the well will be plugged and abandoned setting cement plugs at same depths they were found.

docs\amerada3.app