

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well ☐ gas ☐ well ☐ other Water Injection Well

2. NAME OF OPERATOR
Anadarko Production Company

3. ADDRESS OF OPERATOR
P. O. Box 806 Eunice, New Mexico 88231

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 10' FSL & 660' FWL Sec 11
AT TOP PROD. INTERVAL: T 20S R 33E
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input checked="" type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input type="checkbox"/>	<input type="checkbox"/>
(other)		

5. LEASE
NM - 05148

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME
Teas Yates Unit

8. FARM OR LEASE NAME
Tract # 13

9. WELL NO.
2

10. FIELD OR WILDCAT NAME
Teas Yates

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec 11 T 20S R 33E

12. COUNTY OR PARISH
Lea

13. STATE
N. M.

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
3583.4 GL

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. RUPU Unset PKR. TOH w/PKR & Inj tbq.
2. RU Wireline Co. Pump down backside of 4½" csg w/RA material. Run tracer to perforations to locate channel in 4½" cement jobs
3. Cut off 4½" liner. TOH. w/4½" liner. RU cementer. TIH w/ cement retainer. Squeeze 50 SX cement thru channel in cement between 4½" liner & 7" casing.
4. TIH w/bit. Drill cement to top of 4½" stub.
5. TIH w/ 4½" csg patch & 4½" csg.
6. TIH w/ 4½" Injection PKR & Tbg. RDPV.
7. Resume water injection.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Harold D. Hackett TITLE Field Foreman DATE July 26, 1984

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____ DATE 8-21-84

Subject to
Like Approval
by State

*See Instructions on Reverse Side

RECEIVED

AUG 24 1984

U.S. DEPT. OF JUSTICE
HOOVER OFFICE