ERGY AND MINERALS DE	PAR	TME	NT
			]
DISTRIBUTION			]
SANTA FE			
FILE	1_		l
U.S.Q.S.	1		Į
LAND CFFICE	<u> </u>	<u>i                                     </u>	1

9 O 110 V 2000	Form C-103 .	
P. O. BOX 2088  SANTA FE SANTA FE, NEW MEXICO 87501	Revised 10-1-78	
FILE	5a. Indicate Type of Lease	
U.S. a.S.	State X Fee	
LAND CFFICE	5, State Ot: 6 Gas Lease No.	
OPERATOR	5, State Cit. & Gas Lease No.	
	mmmmmm	
SUNDRY NOTICES AND REPORTS ON WELLS		
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	7. Unit Agraement Name	
640 IV	1, on Adidenant trons	
OIL WELL X OTHER-	8. Farm or Lease liame	
a.t. ol Oparator	<u> </u>	
Alpha Twenty-One Production Company	JO 9. Well No.	
adress of Operator		
F.O. Box 1206	1	
ocation of Well	10. Field and Pool, or Wildcat	
CHIT LETTER N 1944 FEET FROM THE West LINE AND 660 FEET I	Eumont Gas	
·		
Fouth LINE, SECTION 6 TOWNSHIP 19-S RANGE 37-E	MPM. (	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County	
3717.4 GR	Lea	
Check Appropriate Box To Indicate Nature of Notice, Report or	Other Data	
• • •	ENT REPORT OF:	
NOTICE OF INTENTION TO:		
PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING	
	PLUS AND ABANDONMENT	
APCHARILY ABANDON COMMENCE DRILLING OPHS.	PEUG AND ABANDONMENT	
CHANGE PLANS CASING TEST AND CEMENT JOB	لسا	
OTHER		
3°828		
Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, inclu	ding estimated date of starting any proposed	
pork) SEZ RULE 1103.		
work) SEE RULE 1103.		
1. Rig up unit		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 6. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load. 7. Frac Queen formation with 50% CO <sub>2</sub> , and send.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 7. Swab back acid load. 7. Frac Queen formation with 50% CO2, and sand. 7. Swab back Frac fluid.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load. 7. Frac Queen formation with 50% CO2, and send.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load. 7. Frac Queen formation with 50% CO <sub>2</sub> , and sand. 6. Swab back Frac fluid. 6. Run rods and put on pump.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load. 7. Frac Queen formation with 50% CO <sub>2</sub> , and sand. 6. Swab back Frac fluid. 6. Run rods and put on pump.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load. 7. Frac Queen formation with 50% CO <sub>2</sub> , and sand. 6. Swab back Frac fluid. 6. Run rods and put on pump.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 6. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 7. Swab back acid load. 7. Frac Queen formation with 50% CO <sub>2</sub> , and send. 8. Swab back Frac fluid. 11. Run rods and put on pump.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load. 7. Frac Queen formation with 50% CO <sub>2</sub> , and sand. 6. Swab back Frac fluid. 6. Run rods and put on pump.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load. 7. Frac Queen formation with 50% CO <sub>2</sub> , and send. 7. Swab back Frac fluid. 7. Run rods and put on pump.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 7. Swab back acid load. 7. Frac Queen formation with 50% CO <sub>2</sub> , and send. 8. Swab back Frac fluid. 11. Run rods and put on pump.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 7. Swab back acid load. 7. Frac Queen formation with 50% CO <sub>2</sub> , and send. 7. Swab back Frac fluid. 7. Run rods and put on pump. 7. Completion operations will begin within the next week.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 6. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 7. Swab back acid load. 7. Frac Queen formation with 50% CO <sub>2</sub> , and send. 8. Swab back Frac fluid. 11. Run rods and put on pump.		
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 7. Swab back acid load. 7. Frac Queen formation with 50% CO2, and send. 7. Swab back Frac fluid. 7. Run rods and put on pump. 7. Completion operations will begin within the next week. 8. Swab back Frac fluid. 9. Completion operations will begin within the next week.	50 <b>'-3</b> 850 <b>'.</b>	
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load. 7. Frac Queen formation with 50% CO2, and send. 7. Swab back Frac fluid. 7. Run rods and put on pump. 7. Completion operations will begin within the next week.	50 <b>'-3</b> 850 <b>'.</b>	
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 7. Swab back acid load. 7. Frac Queen formation with 50% CO2, and send. 7. Swab back Frac fluid. 7. Run rods and put on pump. 7. Completion operations will begin within the next week.	50 <b>'-3</b> 850 <b>'.</b>	
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 6. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load. 6. Frac Queen formation with 50% CO <sub>2</sub> , and send. 6. Swab back Frac fluid. 6. Run rods and put on pump. 6. Completion operations will begin within the next week. 6. Drilling Superintendent	50°-3850°.	
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 6. Acidize with 3000 gals. approximately, of NEFE 15%. 6. Swab back acid load. 6. Frac Queen formation with 50% CO <sub>2</sub> , and send. 6. Swab back Frac fluid. 6. Run rods and put on pump. 6. Completion operations will begin within the next week. 6. Ompletion operations will begin within the next week. 6. ORIGINAL SIGNED BY	50 <b>'-3</b> 850 <b>'.</b>	
1. Rig up unit 2. Run 2-3/8" tubing to top of the float collar. 3. Circulate 2% KCl water to fill casing. 4. Pressure test 5½" casing to 1000 psi for 30 minutes. 5. Run cased-hole logs: Collar-Gamma Ray-Neutron log. 6. Perforate Queen zone with approximately 13 holes between 37 7. Acidize with 3000 gals. approximately, of NEFE 15%. 8. Swab back acid load. 7. Frac Queen formation with 50% CO2, and send. 8. Swab back Frac fluid. 11. Run rods and put on pump. Completion operations will begin within the next week.	50°-3850°.	