Submit 3 Copies     State of New Mexico       D Appropriate     Ei _,y, Minerals and Natural Resources Depaient		Form C-103 Revised 1-1-89			
DISTRICT I OIL CONSEI	WELL API NO.				
P. O. Box 1980, Hobbs, NM 88240 P. O. Box 2088					
		30-025-28128			
		5. Indicate Type of Lease			
811 S. 1st Street, Artesia, NM 88210-2834		State X Fee			
		6. State Oil & Gas Lease No.			
1000 Rio Brazos Rd., Aztec, NM 87410		E-5231			
SUNDRY NOTICES AND REPORTS					
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"		7. Lease Name or Unit Agreement Name			
(FORM C-101) FOR SUCH PROPOSALS)		BACC CTATE			
1. Type of Well		BASS STATE			
Oil Well Gas Well Other					
2. Name of Operator		8. Well No			
Bass Enterprises Production Company		6			
3. Address of Operator		9. Pool Name or Wildcat			
P. O. Box 2760 Midland, Texas 79702-2760		SALT LAKE YATES			
4. Well Location					
Unit Letter <u>C</u> : <u>330</u> Feet From The	North Line and 1650	Feet From The West Line			
Section 18 Township 20S	Range 33E NMPM				
10. Elevation (Show whether DI		Lea County			
3523.6' GL	, 100, 101, 00, 00,				
11. Check Appropriate Box to Indicate	Nature of Notice Report or	Other Data			
NOTICE OF INTENTION TO:					
		NT REPORT OF:			
		ALTERING CASING			
TEMPORARILY ABANDON CHANGE PLANS					
	COMMENCE DRIELING OPNS.	PLUG AND ABANDONMENT			
PULL OR ALTER CASING	CASING TEST AND CEMENT JOB				
OTHER:	OTHER:				
12 Describe Proposed or Completed Operations (Clearly state all and the it					
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.					
Bass Enterprises Production Company requests approval to plug and abando	on the referenced well. Mark will be sime a set				
project should be 3 days after start. The procedure as follows:	share referenced wen. Work will begin soo	in after approval. Completion of the			
1) MIRU Plugging Co. equipment. Unseat pump and POOH with rods and pl	Imp. LD rods and tubing while POOH.				
<ol><li>ND WH. NU BOP. POOH with 2-3/8" tubing and visually inspect for holes</li></ol>	while POOH, Taily tubing BIH and tag TF	0@3079'.			
3) RU Pump truck to tubing and circulate 5-1/2" casing with 84 bbls FW. Mix	and spot 29 sx cmt (Class C Neat 14 8 p	pg 1 32 vield + 2% CaCl 2brs numn time)			
4) POH to 2700, LD tubing while POOH. Reverse tubing clean using 10.5 bbis FW. WOC and tag. TOC must be no lower than 2972'					
5) PUH to 2700'. Load hole using 9.5 ppg mud laden fluid (69 bbls). Mix and	spot 180 sx same cmt. TOC @ 900'.				
6) ND BOP. Mix and spot 10 sx surface plug using same cement. POOH and	d LD rest of tubing.				
<ol> <li>RD PU. Cut off WH and install New Mexico dry hole marker. Remove dead</li> <li>Contact OCD in Hobbs(505) 393-6161 when well plugging is finished.</li> </ol>	Imen. Clean location.	ON MUST BE NOTIFIED 24			
o) contact cob in hobbs(.505) 550-6101 when wer plugging is infished.	HOURS PRIOR	TO THE BUGINERING OF			
		RATIONS FOR THE C-103			
	TO BE APPROV				
P 966 241 531- JDL PGS					
I hereby certify that the information above is true and complete to the best of my know	ledge and belief.				
SIGNATURE VITE Run (		. 1 1			
SIGNATORE <u>ULCI C. Dura</u>	TITLE: Division Production Superinter	ident DATE: 2/22/97			
	-	ELEPHONE NO. (915) 683-2277			
(This space for State Use)					
ORIGINAL SIGNED BY UTING WILLIAMS					
		3FC 3 0 199			
	TITLE:	DATE:			
		,			

CONDITION	S OF AP	PROVAL	JE /	٩N١