

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-30534
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V 1618
7. Lease Name or Unit Agreement Name New Mexico FH State Com.
8. Well No. 1
9. Pool name or Wildcat Salt Lake Morrow South

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Exxon Corporation
3. Address of Operator P.O. Box 1600, Midland, TX 79702	4. Well Location Unit Letter <u>F</u> : <u>1980</u> Feet From The <u>North</u> Line and <u>1420</u> Feet From The <u>West</u> Line Section <u>32</u> Township <u>20S</u> Range <u>33E</u> NMPM <u>Lea</u> County <u></u>
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3616 GL	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Exxon requests permission to Plug & Abandon the above captioned well.

Give NMOCC 24 hrs notice, NU BOPs and test, POOH w/ PKR.  
Set CIBP @ 12,550' and test. Spot 10 sxs CLH on CIBP.  
Displace hole w/ 10 ppg salt mud.  
Spot 25 sxs of CLH from 12375' - 12175'.  
Spot 25 sxs of CLH from 11360' - 11160'.  
Spot 25 sxs of CLH from 8390' - 8190'.  
Cut off 5 1/2 csg at approx. 7500'.  
Spot 55 sxs of CLH from 100' inside of 5 1/2 csg to 100' above stub.  
Spot 70 sxs of CLC from 5000' - 4800'.  
Pump 1100 sxs of Salt cmt. from 3200' to surface.  
Remove well head, erect dry hole marker and clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Stephen Johnson TITLE Administrative Specialist DATE 1-4-90  
TYPE OR PRINT NAME Stephen Johnson (915) 688-7548 TELEPHONE NO.

(This space for State Use)

Orig. Signed by  
Paul Kautz  
Geologist

APPROVED BY  TITLE  DATE   
CONDITIONS OF APPROVAL, IF ANY:

JAN 08 1990