Form 3160-5 UNITED STATES SUBMIT IN TRIPLICALE®	Form approved. Budget Bureau No. 1004-0135 Expires August 31, 1985
(November 1983) (Formerly 9-331)  DEPARTMENT OF THE INTERIOR verse side)	5. LEASE DESIGNATION AND SERIAL NO
BUREAU OF LAND MANAGEMENT RECEIVED	NM 57280
SUNDRY NOTICES AND REPORTS ON WELLS  (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  Use "APPLICATION FOR PERMIT-" for suffering seals.)	6. IF INDIAN, ALLOTTEE OR TEIBE NAME
	7. UNIT AGREEMENT NAME
O'L NAME OF OPERATOR AREA H. HS	8. FARM OR LEASE NAME
Stevens & Tull, Inc.	Federal "9"
3. ADDRESS OF OPERATOR  D. O. D. 11005 Midland Toylor 70702	9. WELL NO.
P. O. Box 11005, Midland, Texas 79702  4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*	10. FIELD AND POOL, OR WILDCAT
See also space 17 below.) At surface	West Teas
2310' FNL & FEL tenit G	11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA
	Sec. 9, T-20-S, R-33
14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.)	12. COUNTY OR PARISH 13. STATE
30-025-31035 3545' GR	Lea NM
16. Check Appropriate Box To Indicate Nature of Notice, Report, or O	Other Data
NOTICE OF INTENTION TO:	ENT REPORT OF:
TEST WATER SHUT-OFF PULL OR ALTER CASING WATER SHUT-OFF	REPAIRING WELL
FRACTURE TREAT  MULTIPLE COMPLETE  FRACTURE TREATMENT  SHOOT OF ACIDIZE  ABANDON*  SHOOTING OR ACIDIZING	ALTERING CABING ABANDONMENT®
THE PAIR WELL CHANGE PLANS (Other) Completion	on X
(Other) Completion or Recomple	of multiple completion on Well etion Report and Log form.)
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.) *	including estimated date of starting any it depths for all markers and gones perti-
1) 11/29/90 Perforate 3365' - 74' (15 shots)	
2) 11/30/90 Acidize 3365' - 74' with 500 gallons 15% NE-FE. Rec	
3) 12/01/90 Set Cast Iron Bridge Plug at 3360'. Perforate 3330'	
4) 12/03/90 Acidize 3330' - 43' with 750 gallons 15% NE-FE. Rec	cover sulfur water.
5) 12/04/90 Set Cast Iron Bridge Plug at 3325' with 2 sacks ceme	ent. Perforate 3241,
45, 49 and 57 (4 shots).	
6) 12/05/90 Acidize 3241' - 57' with 1000 gallons 15% NE-FE. Re	ecover sul <b>f</b> ur water.
7) 12/06/90 Set Cast Iron Bridge Plug at 3235' with 2 sacks ceme	
3162' (18 holes).	
8) 12/07/90 Acidize 3042' - 3162' with 2000 gallons 15% NE-FE.	Recover sul <b>f</b> ur water.
- Will be requesting permission to plug soon -	

## \*See Instructions on Reverse Side

DATE .

Rodney U. Seale

(This space for Federal or State office use)