

BRITT B NO. 10

WELL DATA

TD: 6980' PBD: 6580' ELEV: 3555' GL ZERO: 11' AGL

CASING: 13-3/8", 48#, H-40 Surface Casing @ 341' w/400 sxs
9-5/8", 36#, H-40 Intermediate Casing @ 3999' w/2200 sxs
7", 20 & 23#, J-55 Production Casing @ 6979' w/370 sxs

TUBING: 1 jt - 2-7/8" OPMA @ 6509'
210 jts - 2-3/8" EUE 8rd J-55 @ 6478'

PERFS: Drinkard: 6670'-80', 6688'-96', 6708'-16', 6720'-26', 6731'-38', 6750'-58',
6770'-75', 6814'-20', 6823'-31', 6835'-54', 6878'-6918'
All Drinkard Perfs Squeezed

Tubb: 6496'-6505', 6508'-12', 6524'-34', (Perfs @ 6430'-44' & 6454'-68' were squeezed)

Blinebry: 5782'-5802'

MISCELLANEOUS: 12-1-79 Model "D" packer was milled over & chased downhole to 6580' where packer stopped.

RECOMMENDED PROCEDURE: *Note: Filter all water used during this recompletion.*

1. MIRU workover rig.
 - A. POOH w/rods & pump.
 - B. Install BOP.
 - C. Tag for fill w/2-3/8" production tubing.
 - D. POOH w/2-3/8" production tubing.

NOTE: Model "D" packer chased downhole to 6580'.

2. Pick up & RIH w/6-1/4" bit, drill collars, 7" casing scraper & 2-7/8" workstring.
 - A. Clean out to top of packer (+6580').
 - B. POOH w/2-7/8" workstring, 7" casing scraper, drill collars & 6-1/4" bit.
 - C. RIH w/6-1/8" washover shoe & extension ~~w/1-dogs~~ and wash over packer 2' plus
and POOH w/packer. *w/PKR Packer*

NOTE: 1-30-79 - Ran 6-1/8" washover shoe, extension & 4 D.C.'s and cut over Model "D" packer 2' plus and chased downhole to 6580' where packer stopped.

3. RIH w/6-1/4" bit, drill collars & 2-7/8" workstring.
 - A. Drill out 8' cement & CIBP @ 6660'.
 - B. Drill out cement plugs to 6875'.
 - C. Spot 9 bbls 15% HCl-NE-FE acid (inhibited for 48 hrs @ 120°F) from 6642' to 6851'.
 - D. POOH w/2-7/8" workstring, drill collars & 6-1/4" bit.

NOTE: Use filtered water for rest of procedure.

RECEIVED
JAN 26 1984
O.C.D.
HOBBES OFFICE