

Submit 3 Copies To Appropriate District
Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

1301 W. Grand Ave., Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-025-06129
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Amerada Hess Corporation		6. State Oil & Gas Lease No. B-2406
3. Address of Operator P.O. Box 840, Seminole, Texas 79360		7. Lease Name or Unit Agreement Name: Wood "A" State
4. Well Location Unit Letter C : 660 feet from the North line and 1650 feet from the West line Section 16 Township 20S Range 37E NMPM Lea County		7. Well No. 1
10. Elevation (Show whether DR, RKB, RT, GR, etc.)		9. Pool name or Wildcat Eunice Monument G/SA

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Notify NMOCD 24 hours before RU.

Plan to MIRU plugging unit. Remove wellhead & install BOP. Swab to determine if gas production. If none, TIH & attempt to release pkr. If pkr. stuck, freepoint tbg., jet cut & TOH. Set CIBP above tbg. stub. Load hole & break circ. w/fresh water. Circ. until balanced. Spot 25 sx. cement plug above CIBP, (253' Plug). WOC & tag. Spot plug mud to 1170'. Spot 25 sx. cement plug from 1170' - 917', (intermediate csg. shoe at 1120'). WOC & tag. Spot plug mud to 178'. Shoot circ. holes at 178' & break circ. Pump 30 sx. cement, circ. to surface on backside, leaving csg. full. Install dry hole marker. RDPU, remove deadmen anchors & clean location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

PERF + 592 50' OUT + 1070 TAG @ 1070
NOV 14 2002
RECEIVED
Hobbs
000

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Roy L. Wheeler, Jr. TITLE Specialist - Field Admin. DATE November 4, 2002

Type or print name Roy L. Wheeler, Jr. Telephone No. 915-758-6778

(This space for State use)

APPROVED BY [Signature] DATE 1-24-03
Conditions of approval, if any:

MES

12-1/2" CASING at 128'
Cemented w/ 100 sx
TQC @ Surface (Calculated)
Hole Size 16"

8-5/8" CASING at 1120'
Cemented w/ 400 sx
TDC @ Surface (Calculated)
Hole Size 11"

PACKER STUCK @ 3675'
PULLED 65K# SEVERAL TIMES

5-1/2" CASING at 3678'
Cemented w/225 sx
TOC @ 3397' (Reported)
Hole Size 6-3/4'

TD 3875'
PBTD xxxx'



