

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.O.S.		
LAND OFFICE		
OPERATOR		

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator GULF OIL CORPORATION	8. Farm or Lease Name J.N. Carson (NCT-A)
3. Address of Operator P. O. Box 670, Hobbs, NM 88240	9. Well No. 13
4. Location of well UNIT LETTER <u>J</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>28</u> TOWNSHIP <u>21S</u> RANGE <u>37E</u> NMPM.	10. Field and Pool, or Wildcat Undes. Eumont
15. Elevation (Show whether DF, RT, GR, etc.) 3433' GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Kill well if necessary. POH with tubing. Set CIBP at 2510'; cap CIBP with 35' cement. Circulate abandonment mud; pressure test CIBP & casing to 500#. Perforate 7" casing at 350' with (4) 1/2" JH in a plane with 90° phasing. Establish circulation down 7" casing, thru perf, and out 7" - 10-3/4" annulus. If necessary run treating packer on tubing and use some HCL to establish circulation. Set cement retainer at 300'; re-establish circulation. Cement with 100 sacks Class "C" cement + 4% gel + 6# salt/sack followed by 100 sacks "C" neat. Pull out of cement retainer; if necessary reverse out excess cement. POH with tubing. ND BOP & wellhead. Spot a 50' surface cement plug; install dry hole marker. Clean and clear location as required.

THE COMMISSION MUST BE RECEIVED  
24 HOURS PRIOR TO COPIES TO WORK

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Russell Worley TITLE Area Engineer DATE 7-22-80APPROVED BY John R. [unclear] TITLE Geologist DATE 10-23-1980

CONDITIONS OF APPROVAL IF ANY: