

NEW MEXICO OIL CONSERVATION COMMISSION

Santa Fe, New Mexico

MISCELLANEOUS NOTICES

Submit this notice in TRIPLICATE to the District Office, Oil Conservation Commission, before the work specified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See additional instructions in the Rules and Regulations of the Commission.

Indicate Nature of Notice by Checking Below

NOTICE OF INTENTION TO CHANGE PLANS		NOTICE OF INTENTION TO TEMPORARILY ABANDON WELL		NOTICE OF INTENTION TO DRILL DEEPER	
NOTICE OF INTENTION TO PLUG WELL		NOTICE OF INTENTION TO PLUG BACK		NOTICE OF INTENTION TO SET LINER	
NOTICE OF INTENTION TO SQUEEZE	<input checked="" type="checkbox"/>	NOTICE OF INTENTION TO ACIDIZE		NOTICE OF INTENTION TO SHOOT (Nitro)	
NOTICE OF INTENTION TO GUN PERFORATE		NOTICE OF INTENTION (OTHER) <u>Fracture treat</u>	<input checked="" type="checkbox"/>	NOTICE OF INTENTION (OTHER)	

OIL CONSERVATION COMMISSION
SANTA FE, NEW MEXICO

Hobbs, New Mexico
(Place)

April 19, 1956
(Date)

Gentlemen:

Following is a Notice of Intention to do certain work as described below at the.....

Gulf Oil Corporation..... Eunice King Well No. 16 in A.....
(Company or Operator).....Lease..... (Unit)
NE 1/4 NE 1/4 of Sec. 28....., T. 21-S....., R. 37-E....., NMPM., Hare..... Pool
(40-acre Subdivision)
Lea..... County.

FULL DETAILS OF PROPOSED PLAN OF WORK
(FOLLOW INSTRUCTIONS IN THE RULES AND REGULATIONS)

SEE ATTACHED SHEET

Approved....., 19.....
Except as follows:

Approved
OIL CONSERVATION COMMISSION

By.....
Title.....

Gulf Oil Corporation
Company or Operator

By.....

Position.....Area Supt. of Prod.
Send Communications regarding well to:

Name.....Gulf Oil Corporation

Address.....Box 2167, Hobbs, New Mexico

HOSEA OFFICE 000

20 APR 69 PM 2:34

In order to return well to production it is proposed to squeeze cement and fracture treat as follows:

1. Drill out cement plugs and clean out to approximately 7600'.
2. Set bridge plug on electric line in 5-1/2" OD liner at approximately 7595'. Dump 2 sacks cement on top plug.
3. Run tubing with Baker parent packer and set in 7" casing. Pressure test casing. Pull tubing and packer.
4. Set cement retainer at 7557'; run tubing, then squeeze cement below retainer. Attempt to stage cement.
5. Run Gamma Ray-Neutron log. Remainder of work will be contingent upon results of tracer survey.

1. The first part of the report

2. The second part of the report

3. The third part of the report

4. The fourth part of the report