

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-08791-05971
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Lease Name or Unit Agreement Name State A AC 2
2. Name of Operator Clayton Williams Energy, Inc.	8. Well No. 2
3. Address of Operator Six Desta Drive, Suite 3000 Midland, Texas	9. Pool name or Wildcat Eunice 7 Rvrs Queen South
4. Well Location Unit Letter L : 1980 Feet From The South Line and 660 Feet From The West Line Section 5 Township 22S Range 36E NMPM Lea County	10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3602 DF

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	SUBSEQUENT REPORT OF:
NOTICE OF INTENTION TO:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. Work will Commence upon OCD approval

- 1) Set CIBP @  $\pm 3550'$ . Dump Bail 35' of cement on CIBP
- 2) Circulate the hole from CIBP to surface w/10# gelled brine
- 3) Perforate the 7" csg @  $\pm 275'$ .
- 4) Circulate cement down the 7" casing and up the 7"/ 9-5/8" annulus to surface.  
( 85 sx Class "C" cement w/2% CaCl<sub>2</sub>)
- 5) Cut the 7" and 9-5/8" csg 3' below GL. Set P & A marker. Cut dead men.  
Clear location of all junk.

PLUG AND ABANDON WELLBORE

\*See Attached Wellbore Diagram\*

I hereby certify that the information above is true and completed to the best of my knowledge and belief.

SIGNATURE David G. Grafe TITLE Senior Prod. Engineer DATE 06/08/94

TYPE OR PRINT NAME David G. Grafe TELEPHONE NO. 682-6324

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

JUN 13 1994